

# Instructions for Add-On-Board      CAT # AB-102

Select the voltage range: Put a drop of solder on the appropriate spots on the back of the board in one of the ovals marked 20V, 200V or 1000V.

Select the decimal point: Put a solder drop on either DP3, DP2 or DP1.

The add-on-board attaches to the 10 pin header on the back of the meter. For PM-102B, use the 10 pin socket on the add on board. Make sure pins 1 and 10 line up. There are numbers on both the meter and the add-on-board at pins 1 and 10.

Connect 5 Vdc to the power spots on the add-on board observing correct polarity.

## CORRECT ALIGNMENT OF ADD-ON BOARD

(meter is upside-down relative to add-on board)

