



PIN	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
SEG	COM	DP2	2E	2D	2C	DP1	1E	1D	1C	1B	1A	1F	1G	2B	2A	2F	2G	COM

NOTE: PINS 1 & 18 SHOULD BE CONNECTED TO BACKPLANE SIGNAL