

3-CHANNEL PWM MODULE

CAT# PFM-2

Setting Parameters:

Eight pushbuttons on module are used to set the frequency and duty cycle. Each of the duty cycles can be adjusted independently. Settings are saved when power goes down.

Frequency is divided into four ranges:

- 1Hz to 999Hz (no decimal point on display)
- 1KHz to 9.99KHz (decimal point in hundreds place X.XX)
- 10KHz to 99.9KHz (decimal point in tens place XX.X)
- 1KHz to 150KHz (decimal point in tens and hundreds place X.X.X)

Duty cycle: 0 to 100%

All parameter automatically saved during power-down.

