

# TECHNICAL INFORMATION







## Positions and connections for 3-way switches • Function 4

Double pole switches in a four pole case




Dotted line between poles : jumper to be wired by the user.

### FUNCTION 4 - TYPE TH (PREFERRED) - 12000 SERIES



→ KEYWAY

E : input  
S : output



TH